

ETVST101-370-20F

Printed Matter No. 9836 8433 01
Publication Date 2020-03-06

Electric angle nutrunner

Valid from Serial No. C1460001
Valid to Serial No. C2439999

Product Instructions

ETV ST101-370-20-F
(90-370 Nm)

8433208248



WARNING

Read all safety warnings and instructions

Failure to follow the safety warnings and instructions may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference

Atlas Copco

Table of Contents

Product information	4
General information	4
Symbols on the tool	4
Safety signal words	4
Warranty	5
ServAid	5
Website.....	5
Safety Data Sheets MSDS/SDS	5
Product safety video for nutrunners.....	5
Country of origin	6
Dimensional drawings	6
Overview	6
The Tensor system.....	6
Technical data	6
Service overview.....	6
Service recommendations	6
Installation	8
Installation requirements.....	8
Tool display	8
Connecting the tool.....	8
Grounding.....	8
Socket release function	8
Installation instructions	8
Installation	8
Fitting of the tool cable	9
Clamping the Tensor tool to a fixture.....	9
Operation	10
Ergonomic guidelines	10
Operating instructions.....	10
Operating.....	10
Service	12
Preventing ESD problems	12
Maintenance instructions	12
Overhaul	12
Service recommendations	12
Service instructions	12
Lubrication instructions	13
Lubricating guide	13
Lubrication	13
Repair instructions	13
Repair.....	13
Troubleshooting	14

Power Focus 600/6000.....	14
Power Focus 3000/4000.....	14
If the tool becomes very hot.....	14
Recycling.....	15
Recycling instruction.....	15
Recycling information	15

Product information

General information


WARNING Risk of Property Damage or Severe Injury

Ensure that you read, understand and follow all instructions before operating the tool. Failure to follow all the instructions may result in electric shock, fire, property damage and/or severe bodily injury.

- ▶ Read all Safety Information delivered together with the different parts of the system.
- ▶ Read all Product Instructions for installation, operation and maintenance of the different parts of the system.
- ▶ Read all locally legislated safety regulations regarding the system and parts thereof.
- ▶ Save all Safety Information and instructions for future reference.

Symbols on the tool

The symbols on the tool have the following meanings:



A	Directive 2006/42/EC on Machinery specifies the essential health and safety requirements the product has to meet in order for the manufacturer to affix the CE marking.
B	When operating the device be sure to use caution.
C	The symbol indicates that parts within the product must be handled in accordance with the WEEE Directive.
D	Read the instruction manual/booklet before starting work or before operating equipment or machinery.

Safety signal words

The safety signal words Danger, Warning, Caution, and Notice have the following meanings:

DANGER	DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.
WARNING	WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.
CAUTION	CAUTION, used with the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to personal injury.

Warranty

- Product warranty will expire 12 months after the product is first taken into use, but will in any case expire at the latest 13 months after delivery.
- Normal wear and tear on parts is not included within the warranty.
 - Normal wear and tear is that which requires a part change or other adjustment/overhaul during standard tools maintenance typical for that period (expressed in time, operation hours or otherwise).
- The product warranty relies on the correct use, maintenance, and repair of the tool and its component parts.
- Damage to parts that occurs as a result of inadequate maintenance or performed by parties other than Atlas Copco or their Certified Service Partners during the warranty period is not covered by the warranty.
- To avoid damage or destruction of tool parts, service the tool according to the recommended maintenance schedules and follow the correct instructions.
- Warranty repairs are only performed in Atlas Copco workshops or by Certified Service Partners.

Atlas Copco offers extended warranty and state of the art preventive maintenance through its ToolCover contracts. For further information contact your local Service representative.

For electrical motors:

- Warranty will only apply when the electric motor has not been opened.

ServAid

ServAid is a portal that contains technical information for all hardware and software products, such as:

- Regulatory and Safety information
- Technical data
- Installation, Operation and Service instructions
- Spare parts lists
- Accessories

ServAid is continuously updated and is available at: <https://servaid.atlascopco.com>

For further information contact your local Atlas Copco representative.

Website

Log in to Atlas Copco: www.atlascopco.com.

You can find information concerning our products, accessories, spare parts and published matters on our website.

Safety Data Sheets MSDS/SDS

The safety data sheets describes chemical products sold by Atlas Copco.

For more information, consult the website:

www.atlascopco.com/sds

Product safety video for nutrunners

Learn more about safety features on Atlas Copco nutrunners and what measures the operator has to take for a safe operation. Click the link or scan the QR code below to view the video:

<https://www.youtube.com/watch?v=FAh6yttvUpw>



Country of origin

Please refer to the information on the product label.

Dimensional drawings

For information about the dimensions of a product, see the Dimensional drawings archive:

<http://webbox.atlascopco.com/webbox/dimdrw>

Overview

The Tensor system

The Tensor system consists of a range of tightening tools powered by brushless electric motors and different drive units.

Motors are available in different sizes. All tools are protected from overheating of the motor. Electrical protection system is based on an earth fault circuit breaker, Earth Fault Protector (EFP). The EFP senses small current leakage (>30mA) and if leakage occurs, the drive is switched off (30ms). Changing, interfering or tampering with the protection system voids all warranty and obligations from Atlas Copco. Trouble-shooting and re-start of the system may only be carried out by an authorized person. Check the function of the EFP on a regular basis by pressing the trip-button. The EFP should switch off accordingly.

Technical data

Ordering No	8433208248
Model	ETV ST101-370-20-F
Model type	Angle
Distance center to side	33 mm
Speed	280 r/min
Length	672 mm
Torque range	90–370 Nm
Torque range	66–273 ft lb
Square drive	3/4 in
Weight	7.3 kg
Weight	16.1 lb
Height	62 mm
Motor power	1500 W
Motor voltage	200 V
Motor voltage type	3 a.c.

Service overview

Service recommendations

Preventive maintenance is recommended at regular intervals. See the detailed information on preventive maintenance. If the product is not working properly, take it out of service and inspect it.

If no detailed information about preventive maintenance is included, follow these general guidelines:

- Clean appropriate parts accurately

- Replace any defective or worn parts

Installation

Installation requirements

Tool display

The tool display is turned on from the controller.

On Power Focus 4000:

- Push the Prog button
- Use the navigation buttons to follow the path > Tool > Configuration > Accessory bus > ST bus > Mode

Connecting the tool

The tool should, via its correct Power Focus drive unit, be connected to the mains, 230V/50Hz alternatively 115V/ 60Hz, single phase. See instructions for your Power Focus drive unit.

Grounding

If the tool is mounted in a handheld or hand guided fixture, the fixture should be connected to the drive using a separate 2.5mm² grounding cable.

Socket release function

It is recommended to use the socket release function on all the ETP ST101 tools. When the function is enabled, the socket rotates backwards 3° after a completed tightening. The aim is to reduce tension on the reaction bar and to make it easier to remove the tool.

The socket release function is turned on from the controller.

On Power Focus 4000:

- Push the Prog button
- Use the navigation buttons to follow the path > Pset > Programming+ > Options > Socket release > Mode On


Installation instructions

Installation

The tool should, via its correct POWER FOCUS/drive unit, be connected to the mains, 230V/ 50Hz alternatively 115V/ 60Hz, single phase. See instructions for your POWER FOCUS/ drive unit.

Fitting of the tool cable:

- Security check that the cable type is correct
- Align the cable connector using the two asymmetrically positioned heads on the connector to fit in the slots in the tool handle.
- Tighten the lock nut.
- Security check that the connection is correct by pulling, pushing and turning the cable connector (there should be no movement).

-  The tool has a built in electronic memory chip that will transmit the torque transducer calibration value and angle pulses to the POWER FOCUS/drive unit. Any changes made of these values in the POWER FOCUS while the tool is connected will be stored in the tool memory.


Fitting of the tool cable

- Make sure that the tool cable is of correct type.
 - Align the cable connector using the two asymmetrically positioned heads on the connector to fit in the slots in the tool handle.
 - Tighten the lock nut.
 - Make sure that the connection is correct by pulling, pushing and turning the cable connector (there should be no movement).
- i** The tool has a built in electronic memory chip that will transmit the torque transducer calibration value and angle pulses to the POWER FOCUS/drive unit. Any changes made of these values in the POWER FOCUS while the tool is connected will be stored in the tool memory.

Clamping the Tensor tool to a fixture

To clamp the tool to a fixture, only the areas marked grey on the figure can be used. However, be careful not to damage the rubber coating when clamping the rubber handle.

NOTICE The white areas in the picture must not be used for fixturing.



Operation

Ergonomic guidelines

Consider your workstation as you read through this list of general ergonomic guidelines and see if you can identify areas for improvement in posture, component placement, or work environment.

- Take frequent breaks and change work positions frequently.
- Adapt the workstation area to your needs and the work task.
 - Adjust for convenient reach range by determining where parts or tools should be located to avoid static load.
 - Use workstation equipment such as tables and chairs appropriate for the work task.
- Avoid work positions above shoulder level or with static holding during assembly operations.
 - When working above shoulder level, reduce the load on the static muscles by reducing the weight of the tool, using for example torque arms, hose reels or weight balancers. You can also reduce the load on the static muscles by holding the tool close to the body.
 - Make sure to take frequent breaks.
 - Avoid extreme arm or wrist postures, particularly for operations requiring a degree of force.
- Adjust for convenient field of vision by minimizing movement of the eyes and head during the work task.
- Use the appropriate lighting for the work task.
- Select the appropriate tool for the work task.
- Use ear protection equipment in noisy environments.
- Use high-quality inserted tools or consumables to minimize exposure to excessive levels of vibration.
- Minimize exposure to reaction forces.
 - When cutting:

A cut-off wheel can get stuck if the wheel is either bent or if it is not guided properly. Make sure to use the correct flanges for cut-off wheels and avoid bending the wheel during cut-off operation.
 - When drilling:

The drill might stall when the drill bit breaks through. Make sure you use support handles if the stall torque is too high. The safety standard ISO11148 part 3 recommends using something to absorb the reaction torque above 10 Nm for pistol grip tools and 4 Nm for straight tools.
 - When using direct-driven screw or nutrunners:

Reaction forces depend on tool setting and joint characteristics. The ability to bear reaction forces depends on the operator's strength and posture. Adapt the torque setting to the operator's strength and posture and use a torque arm or reaction bar if the torque is too high.
- Use dust extraction system or mouth protection mask in dusty environments.

Operating instructions

Operating

Make sure that the tool is in correct working order and that the controller is correctly programmed to avoid unexpected behaviour from the tool, which may result in operator injury.

Check that the tool is in the correct running direction by looking at the function light situated above the tool handle, by turning the reverse ring (only for ETV/ETD DS or by turning the arm on the trigger knob (only for ETP DS).

The soft-start function facilitates entering the screw head and thread.

The duration of the soft start is adjustable, see the manual for the drive unit.

The tool is equipped with signal lights,


- Green = OK tightening

- Yellow = Warning – low torque (not for ES)
- Red = Warning – high torque
- Orange = Function indicator (only for SL and DL)
- Blue = Function indicator (only for SL)

Service

Preventing ESD problems

The components inside the tool and controller are sensitive to electrostatic discharge. To avoid future malfunction, make sure that service and maintenance is carried out in an ESD approved work environment. The figure below shows an example of an appropriate service workstation.



Maintenance instructions

Overhaul

Service must only be carried out by qualified personnel who have access to the Service instruction and/or have been trained for service on Tensor tools.

- i The electric motor is a sealed unit and may under no circumstances be opened by anyone else than Atlas Copco Industrial Technique AB!

If you decide that the electric motor is defect or in need of service, return the complete motor unit to Atlas Copco Industrial Technique for replacement.

Motors which have been opened by anyone else than Atlas Copco Industrial Technique will not be serviced.

Overhaul and preventive maintenance is recommended at regular intervals once per year or after maximum 250.000 tightening depending on which occurs sooner. More frequent overhaul may be needed if the machine is used in heavy-duty operations. If the machine not is working properly, it should immediately be taken away for inspection.

When dismantling the tool **always** use the specially designed service tool 4080 0848 80, (two service tools are required).

Service recommendations

Preventive maintenance is recommended at regular intervals. See the detailed information on preventive maintenance. If the product is not working properly, take it out of service and inspect it.

If no detailed information about preventive maintenance is included, follow these general guidelines:

- Clean appropriate parts accurately
- Replace any defective or worn parts

Service instructions

Overhaul and preventive maintenance is recommended at regular intervals once per year or after maximum 250.000 tightening depending on which occurs sooner. More frequent overhaul may be needed if used at high torque, high cycle rate or long tightening times. If the machine is not working properly, it should immediately be taken away for inspection.

At the overhauls, all parts should be cleaned accurately and defective or worn parts (i.e. O-rings) should be replaced.

Lubrication instructions

Lubricating guide

Brand	Cable nut	Gears
Molycote		BR2 Plus
CRC	Litium grease No. 3020	

Brand	Angle gears	General purpose
Molycote	Longterm 2 plus	
Almagard		LE 3751

Lubrication

Planetary gears, needle bearings and ball bearings must be lubricated with soft grease containing molybdenumdisulphide at the regular overhaul of the tool.

Repair instructions

Repair

Repair must only be carried out by qualified authorised personnel. For further information contact your local Atlas Copco sales representative.

Troubleshooting

Power Focus 600/6000

Is the unit switched on? Check the earth fault circuit breaker behind the front door. Should it have tripped, make sure to find the primary fault before resuming operation. Check that the wiring on the remote start connector is correct. For further information see 9836 4954/9836 7446.

Power Focus 3000/4000

Is the POWER FOCUS switched on and in RUN mode? Check that the correct POWER FOCUS is used (ST31/ST32/ST61/STR31/STR61-Tensor3-7, ST81-Tensor8-9). Check the fuses for the drive part. Check Drive parameters, refer to the User Guide of the POWER FOCUS/ drive unit. Check the earth fault circuit breaker on the backside of the drive. Should it have tripped, make sure to find the primary fault before resuming operation. Check that the wiring on the remote start connector is correct. For further information see 9836 2258.

If the tool becomes very hot

With proper adjustment the tool can handle any normal line jobs that an operator sustains. What can cause overheating are combinations of some factors: torque above rated, too low speed, too long ramp time (motor has to give high torque for a long time), very high prevailing torque, very soft joints, short cycle time. To correct, look over speed, ramp time, tightening strategy. One stage and Ergoramp are most heat conserving when applicable. Please refer to the User Guide of your POWER FOCUS. If the above corrections are not enough, choose a tool of the next higher capacity.


Recycling

Recycling instruction

When a product has served its purpose it has to be recycled properly. Dismantle the product and recycle the components in accordance with local legislation.

Batteries shall be taken care of by your national battery recovery organization.

Recycling information



ST Angle Tool

	Part:	Recycle as:
1	Angle head	Steel
2	Cap nut	Steel
3	Planeraty gear	Steel
4	Cap nut	Steel
5	Planetary gear	Steel
6	Motor with transducer	WEEE
7	Nut	Steel
8	Insulatione hose	Thermoplastic urethane elastomer (TPU)
9	Cap nut	Steel
10	Speaker	WEEE
11	Led flex card complete	WEEE

12	Reverse ring	Aluminum
13	Electronics module	WEEE
14	Handle body	Aluminum
15	Trigger button	Steel
16	Handle	PA6 GF30
17	Nut	Steel

Original instructions



**Atlas Copco Industrial
Technique AB**
SE-10523 STOCKHOLM
Sweden
Telephone: +46 8 743 95 00
www.atlascopco.com

© Copyright 2020, Atlas Copco Industrial Technique AB. All rights reserved.
Any unauthorized use or copying of the contents or part thereof is prohibited.
This applies in particular to trademarks, model denominations, part numbers
and drawings. Use only authorized parts. Any damage or malfunction caused
by the use of unauthorized parts is not covered by Warranty or Product
Liability.

Out of respect to wildlife and nature, our technical literature is printed on
environmentally friendly paper.