


IRTT-B 5Nm

Spare part list



| Ref.nr. | Bestillingsnr. | Qty | Beskrivelse | Remark / included in Service kit |
|-----------|----------------|-----|-----------------|--|
| 1 (2-3) | 4612900154 | 1 | Encoder, compl. | |
| 2 | | 1 | Encoder | Del er inkludert i settet 4612900154 Encoder, compl. |
| 3 | | 1 | Belt | Del er inkludert i settet 4612900154 Encoder, compl. |
| 4 | 4612239323 | 1 | Brush | |
| 5 (6-7) | 4612900019 | 1 | Bearing kit | |
| 6 | | 1 | Bearing | Del er inkludert i settet 4612900019 Bearing kit |
| 7 | | 1 | Bearing | Del er inkludert i settet 4612900019 Bearing kit |
| 8 | 4612032103 | 1 | PCB | |
| 9 (10-11) | 4612900025 | 1 | Cover, compl. | |
| 10 | | 1 | Cover | Del er inkludert i settet 4612900025 Cover, compl., 4612900030 Cover, compl. |
| 11 | | 1 | Body | Del er inkludert i settet 4612900025 Cover, compl. |